



































 <p>ITEM:205-6101-01C OVEREDGE LOOPER FITS BABY LOCK EA605, BL4-605 BL4-625</p>	 <p>ITEM:405-6101-01C UPPER LOOPER FITS BABY LOCK EF405</p>	 <p>ITEM:405-6101-02B LOWER LOOPER FITS BABY LOCK BL3-318, BL3-406, BL3-407</p>
 <p>ITEM:407-6101-01A UPPER LOOPER FITS BABY LOCK BL3200, BL3-318, BL3-406, BL3-407</p>	 <p>ITEM:418-6101-02A LOWER LOOPER FITS BABY LOCK BL3200, BL3-418, BL4-428, BL4-736</p>	 <p>ITEM:60290 UPPER LOOPER FITS BABY LOCK 300, 5030,</p>
 <p>ITEM:60335 LOWER LOOPER FITS BABY LOCK 300, 5030, 5040, 430</p>	 <p>ITEM:605-6102-01A CHAIN LOOPER FITS BABY LOCK EA605, BL4-605</p>	 <p>ITEM:60768 UPPER LOOPER FITS BABY LOCK 430, 432, 5040L, 4350D</p>










 <p>ITEM:714-6101-01A UPPER LOOPER FITS BABY LOCK BL4-428, BL4-436, BL4-728D</p>	 <p>ITEM:300616 UPPER LOOPER FITS CONSEW 94, NECCHI NL4 MAMMYLOCK ML4</p>	 <p>ITEM:310619 LOWER LOOPER FITS CONSEW 93 MAMMYLOCK NEW HOME 603 PFAFF 603A</p>
 <p>ITEM:310629 UPPER LOOPER FITS CONSEW 93 MAMMYLOCK NEW HOME 603 PFAFF 603A</p>	 <p>ITEM:320708 LOWER LOOPER FITS CONSEW 94 MAMMYLOCK ML4, PFAFF 604</p>	 <p>ITEM:11787 LOWER LOOPER FITS WHITE 503, 534</p>
 <p>ITEM:125000343 UPPER LOOPER FITS TOYOTA 6300,6600 WHITE 634D, 834DW</p>	 <p>ITEM:784083008 LOWER LOOPER FITS JANOME 203, 234, 334D, 634D</p>	 <p>ITEM:A2512234000 UPPER LOOPER FITS JUKI MO134, MO234</p>

 <p>ITEM:X75209001 UPPER LOOPER FITS BROTHER 834D, 934D VIKING M560E</p>	 <p>ITEM:410262 UPPER LOOPER FITS SINGER 14U13, 14U53</p>	 <p>ITEM:410434 UPPER LOOPER FITS SINGER 14U12, 14U52, 14U64, 14234</p>
 <p>ITEM:410452 LOWER LOOPER FITS SINGER 14U12, 14U52, 14U244, 14U285</p>	 <p>ITEM:412553 LOWER LOOPER FITS SINGER 14U13, 14U53</p>	 <p>ITEM:50139403 LOOPER CHAIN FITS BERNETTE SEWING MACHINE: MO334D</p>
 <p>ITEM:A2526-776-000 LOWER LOOPER FITS BERNINA SEWING MACHINE: 2000DE</p>	 <p>ITEM:A2108-104-000 LOWER LOOPER FITS JUKI SEWING MACHINE: MO104</p>	 <p>ITEM:126648-001 LOWER LOOPER FITS BROTHER SEWING MACHINE: B524</p>

 <p>ITEM:127260-001 UPPER LOOPER FITS BROTHER SEWING MACHINE: B524</p>	 <p>ITEM:127814-001 UPPER LOOPER FITS BROTHER SEWING MACHINE: B526, B626</p>	 <p>ITEM:127840-001 LOWER LOOPER FITS BROTHER SEWING MACHINE: B526, 546D</p>
 <p>ITEM:A2512-234-000 UPPER LOOPER FITS JUKI SEWING MACHINE: MO-134, MO-613, MO-623, MO-644D, MO-654DE</p>	 <p>ITEM:X75094001 UPPER LOOPER FITS VIKING SEWING MACHINE: 1000,700, 1002LCD</p>	 <p>ITEM:X75208001 LOWER LOOPER FITS VIKING SEWING MACHINE: 700, 900, 560ED</p>
 <p>ITEM:X76771001 LOWER LOOPER FITS VIKING SEWING MACHINE: PL1500, PL2000</p>	 <p>ITEM:X77340001 LOWER LOOPER FIT BROTHER SEWING MACHINE: 934D, 920D, PL1050 & 640D</p>	 <p>ITEM:407-6104-01C LOOPER SUB. FITS BABY LOCK SEWING MACHINE: BL4-428</p>

 <p>ITEM:60806 LOOPER SUB. FITS BABY LOCK SEWING MACHINE: 803, 804, 843</p>	 <p>ITEM:61294 UPPER LOOPER FITS BABY LOCK SEWING MACHINE: SLE4380ED</p>	 <p>ITEM:61300 LOWER LOOPER FITS BABY LOCK SEWING MACHINE: SLE4380ED</p>
 <p>ITEM:H002581 LOWER LOOPER FITS ELNA SEWING MACHINE: L1, L2, L4 L5</p>	 <p>ITEM:H003583 LOWER LOOPER FITS ELNA SEWING MACHINE: F-3</p>	 <p>ITEM:H004125 LOWER LOOPER FITS ELNA SEWING MACHINE: 904, 905, 614DE, 7044, 714DE</p>
 <p>ITEM:H004117 UPPER LOOPER FITS ELNA SEWING MACHINE: L-904, L-905, PRO4DE/C</p>	 <p>ITEM:H010801 UPPER LOOPER FITS ELNA SEWING MACHINE: 604E, 614DE, 704E</p>	 <p>ITEM:310670A UPPER LOOPER FITS JANOME SEWING MACHINE: 603</p>

 <p>ITEM:624143008 UPPER LOOPER FITS JANOME SEWING MACHINE: COMBI-6</p>	 <p>ITEM:724134009 UPPER LOOPER FITS JANOME SEWING MACHINE: COMBI-DX</p>	 <p>ITEM:784076008 UPPER LOOPER FITS JANOME SEWING MACHINE: 203, 234</p>
 <p>ITEM:ML232 LOWER LOOPER FITS JANOME SEWING MACHINE: 778</p>	 <p>ITEM:ML319 UPPER LOOPER FITS JANOME SEWING MACHINE: 777</p>	 <p>ITEM:310616 UPPER LOOPER FITS NECCHI SEWING MACHINE: NL4</p>
 <p>ITEM:340600 UPPER LOOPER FITS PFAFF SEWING MACHINE: 780</p>	 <p>ITEM:350601 LOWER LOOPER FITS SINGER SEWING MACHINE: 14U595</p>	 <p>ITEM:77013 UPPER LOOPER FITS SINGER SEWING MACHINE: 14J334</p>

 <p>ITEM:77014 LOWER LOOPER FITS SINGER SEWING MACHINE: 14J334</p>	 <p>ITEM:42114 LOWER LOOPER FITS SINGER SEWING MACHINE:</p>	 <p>ITEM:1250003441 LOWER LOOPER FIT TOYOTA SEWING MACHINE:</p>
 <p>ITEM:11776 UPPER LOOPER FITS WHITE 206, 208, 216, 503, 534, 734</p>	 <p>ITEM:330636 UPPER LOOPER FITS PFAFF SEWING MACHINE: 797</p>	 <p>LOWER LOOPER FITS PFAFF SEWING MACHINE: 780 SERIES</p>
 <p>ITEM:350602 UPPER LOOPER FITS SINGER SEWING MACHINE: 14U595</p>	 <p>ITEM:350603 LOWER LOOPER FITS SINGER SEWING MACHINE: 14U595</p>	 <p>ITEM:550568 UPPER LOOPER FITS SINGER SEWING MACHINE: 14U544, 554, 555</p>

 <p>ITEM:A20051000 LOWER LOOPER FITS SINGER SEWING MACHINE: 14T948DS</p>	 <p>ITEM:A30021000 LOWER LOOPER FITS SINGER SEWING MACHINE: 14T948DS</p>	 <p>ITEM:G1070 LOWER LOOPER FITS SINGER SEWING MACHINE:14T957DS</p>
 <p>ITEM:G1152 LOWER LOOPER FITS SINGER SEWING MACHINE:14T957DS</p>	 <p>ITEM:G1261 UPPER LOOPER FITS SINGER SEWING MACHINE:14T957DS</p>	 <p>ITEM:11443 UPPER LOOPER FITS WHITE SEWING MACHINE:523</p>
 <p>ITEM:11444 LOWER LOOPER FITS WHITE SEWING MACHINE:523</p>	 <p>ITEM:11715 UPPER LOOPER FITS WHITE SEWING MACHINE: 228, 534D, 734D, 734DW</p>	 <p>ITEM:12159 UPPER LOOPER FITS WHITE SEWING MACHINE: 8234, 299</p>

 <p>ITEM:12162 LOWER LOOPER FITS WHITE SEWING MACHINE: 8234,S34D</p>	 <p>ITEM:141000239 LOWER LOOPER FITS WHITE SEWING MACHINE: 2000</p>	 <p>ITEM:141000248 UPPER LOOPER FITS WHITE SEWING MACHINE: 2000</p>
 <p>ITEM:141000307 LOWER LOOPER FITS WHITE SEWING MACHINE: 634D, 834DW</p>	 <p>ITEM:141000345 UPPER LOOPER FITS WHITE SEWING MACHINE: 1500, 1600</p>	 <p>ITEM:141000352 LOWER LOOPER FITS WHITE SEWING MACHINE: 1500</p>