



ITEM:314662-001
BOBBIN CASE FITS
SINGER 4613, 4617, 6234



ITEM:383386-931
BOBBIN CASE FITS SINGER
900, 920, 925, 1030



ITEM:383913-002
BOBBIN CASE FITS
SINGER 2010, 6268



ITEM:421325
BOBBIN CASE FITS
SINGER 2302, 2303, 2503,
3317, 7028



ITEM:421326
BOBBIN CASE FITS SINGER
353, 354, 500K, 6100 SERIES



ITEM:1275000
BOBBIN CASE FITS
JANOME TYPE



ITEM:X59802-001
BOBBIN CASE FITS
BABY LOCK BL2150,
BL6150, BL7500



ITEM:XC3153051
BOBBIN CASE FITS BABY
LOCK BLCC, BLDC, BLQC



ITEM:XC0066051
BOBBIN CASE FITS
BROTHER XL3500,
XL6040 XL6050 XL6452,